Experiment - 7

(Working with BMP - 280 sensor)

Aim = To set the client server communication with raspberry pi 4 using UDP protocol to transmit BMP280 data from wifi.

Equipments Required:

- 1. Raspberry Pi-4 Microcontroller Board
- 2. VGA cable, VGA to Hdmi and Hdmi to micro-usb cables.
- 3. BMP-280 sensor
- 4. Jumper wires
- 5. Monitor
- 6. Mouse
- 7. Keyboard

Methodology:

Circuits connections are shown below. Inbelow connection VCC of bmp-280 is connected to 3.3V pin of raspberry pie board and both ground pins are connected together, SCL pin and SDA pins of bmp-280 are connected to GPIO-2 and GPIO-3 pins of raspberry pie 4 board.



Results:- The drive link which contains the photo of results (temperature and pressure) in csv file is:-Drive link

Conclusion: We learnt about the working of BMP-280 and also learnt how to make its connection with raspberry pie, we also understood the code which helps to link BMP-280 and raspberry pie 4 board to obtain data of pressure and temperature.

Code: The code for server annd client is written in THONNY software as shown below:

Server code:

```
import socket
import json
import csv
host = '10.205.2.245'
port = 8000
def setupServer():
 s = socket.socket(socket.AF_INET, socket.SOCK_STREAM)
  print("Socket created.")
 try:
    s.bind((host, port))
  except socket.error as msg:
    print(msg)
  print("Socket bind comlete.")
  return s
def setupConnection():
 s.listen(1) # Allows one connection at a time.
 conn, address = s.accept()
  print("Connected to: " + address[0] + ":" + str(address[1]))
  return conn
def dataTransfer(conn):
 # A big loop that sends/receives data until told not to.
 while True:
    # Receive the data
    data = conn.recv(1024) # receive the data
    data = data.decode('utf-8')
    print(data)
    # Split the data such that you separate the command
    # from the rest of the data.
```

```
dataMessage = data.split(' ', 1)
    command = dataMessage[0]
    dataext = json.loads(data)
    fieldname = dataext.keys()
    with open('/home/redpitaya/Documents/meow.csv', mode = 'a', newline='') as file:
      writer = csv.DictWriter(file, fieldnames = fieldname)
     file.seek(0,2)
      if file.tell()==0:
        writer.writeheader()
      writer.writerow(dataext)
      print()
  # conn.close()
s = setupServer()
while True:
  conn = setupConnection()
  while(True):
    dataTransfer(conn)
Client code:-
#!/usr/bin/env python
import time
from bmp280 import BMP280
try:
 from smbus2 import SMBus
except ImportError:
 from smbus import SMBus
```

```
import socket
host = '10.205.2.245'
port = 8000
s = socket.socket(socket.AF_INET, socket.SOCK_STREAM)
s.connect((host, port))
print("""temperature-and-pressure.py - Displays the temperature and pressure.
Press Ctrl+C to exit!
""")
# Initialise the BMP280
bus = SMBus(1)
bmp280 = BMP280(i2c_dev=bus)
while True:
 temperature = bmp280.get_temperature()
  pressure = bmp280.get_pressure()
  degree_sign = u"\N{DEGREE SIGN}"
 format_temp = "{:.2f}".format(temperature)
  print('Temperature = ' + format_temp + degree_sign + 'C')
 format_press = "{:.2f}".format(pressure)
  print('Pressure = ' + format_press + ' hPa \n')
    jsonData = "{ \"temperature\":" + "{:.2f}".format(temperature) + ", \"pressure\":" + "
{:.2f}".format(pressure) + "}"
 s.send(str.encode(jsonData))
 time.sleep(4)
```